

EGGLE - BERLIN PLUS with Push/Pull Coil Tap & Out-of-Phase Switching Seymour Duncan Pickups




FROM NECK PICKUP

Coil tap inner coil = **red** and **white** to earth
Coil tap outer coil = **green** and **black** to earth

This shows both inner coils live on coil tap.
Swapping the wires will change which coil will be live.



FROM BRIDGE PICKUP



DPDT SWITCH & VOLUME POT

JACK SOCKET

TOGGLE SWITCH

DPDT SWITCH & TONE POT